


# Instruction Manual

- Thank for purchasing a Versa watch winder.
- Please take a few minutes to read through the manual to ensure proper operation.
- Please keep the instruction manual for future reference.

ITEM NO.:G088

**The switch and adapter port can be found on the rear side of the unit.**



◀ Put the watch pillow extender or watch pillow adapter on the watch pillow for larger size wrist watch. The pillow extender and the watch pillow adapter are included in the package.

## Item Specification

Power	AC adapter	DC/4V 500mA
Feature	1.Clockwise, counterclockwise, and bi-directional (auto) settings 2.TPD (Turns Per Day) Mode A: 350TPD Mode B: 650TPD Mode C: 850TPD Mode D: 1050TPD Please note that the watch winder will turn, rest, and turn again for each setting. The watch winder will not turn constantly to prevent over winding of your watch. This is the normal operation for the watch winder.	
Size	241 x 260 x 170 mm (W x H x D)	
Temperature	Operate between 5°C~+40°C	
Weight	About 1.83kg (without adapter)	Accessory AC Adapter

**Note:**

- \* Please use the AC adapter supplied with the unit.
- Input: AC/100-240V, 50-60Hz
- Output: DC/4V 500mA
- \* Remove the adapter when the winder is not in use.
- \* Always turn off the power when inserting or removing watches.

## Operation:

1. Insert the adapter into the adapter port and plug it into the electrical outlet.
2. Open the front cover and use your index finger and thumb to hold the watch holder from both sides and gently pull out the watch holder.
3. Place the watch on the holder by pushing in the spring on the back of the holder, then put your watch around the holder and let go of the spring.
4. Once the watch is on the holder, place the holder back into the winder. Push until you hear a click signifying that it is securely in the winder.
5. To start operation, please set the interval and direction settings on the back of the watch winder.



## Attention:

- \* If you do not use this product for a long time, please switch off the unit.
- \* Make sure to turn the unit off completely before attempting to pull out the watch holder.
- \* For warranty information please contact the retailer you purchased from.